

13. Air Distribution System

S/N	Part number	Part name	Qty.	S/N	Part number	Part name	Qty.
1	Q1841075	Hexagon head flange bolt	14		(Q617B08)		
2	1007120-81D	Rocker arm assembly, exhaust valve	6	12	1007175-81D	Rocker arm shaft assemblies (No. 4, No. 5 and No. 6 cylinders)	1
	(1007120C81D)			13	1007182-81D	Rocker arm shaft pressure block (II)	3
3	1007163-81D	Axial alignment sleeve, rocker arm	6	14	1007181-81D	Rocker arm shaft pressure block (I)	1
4	1007110-81D	Rocker arm assembly, intake valve	6	15	1007165-81D	Rocker arm shaft assemblies (No. 1, No. 2 and No. 3 cylinders)	1
5	1007164-81D	Seat, solenoid valve	2	16	1007012-81D	Bridge, intake valve	6
	(1007164A81D)				(1007012-81DZ)		
6	1007161-81D	Pressure plate, solenoid valve	2	17	1007028-53D	Valve cotter	48
7	CQ2180612	Hexagon socket cylindrical head screw	2	18	1007024-81D	Seat, valve spring	24
	(Q218B0612TF2)			19	1007035-81D	Valve guide oil seal assembly (valve stem seal ring)	24
8	1007162-81D	Solenoid valve assembly, brake	2		(1007035B81D)		
9	GB/T3452.1	O-ring rubber seal 10.6×2.65	2	20	1003014-81D	Valve guide pipe	24
	10.6×2.65			21	1007021-81D	Spring, intake valve	24
10	Q/WC3403-1994	Copper washer 8×14	2	22	1003012-81D	Seat, intake valve	12
	8×14			23	1007011-81D	Intake valve	12
11	CQ61708	Hexagon head plug	2		(1007011-81DH)		

13. Air Distribution System

S/N	Part number	Part name	Qty.	S/N	Part number	Part name	Qty.
	(1007011A81D)						
24	1007016-81D	Exhaust valve	12				
	(1007016-81DH)						
	(1007016A81D)						
25	1003013-81D	Seat, exhaust valve	12				
26	1007023-81D	Inner spring, exhaust valve	12				
27	1007015-81D	Bridge assembly, exhaust valve	6				
	(1007015-81DZ)						
28	1007183-81D	Rocker arm shaft pressure block (III)	1				




Fig. 13 Air distribution system