

24. Fuel Supply System (I)

S/N	Part number	Part name	Qty.	S/N	Part number	Part name	Qty.
1	1104030-775	Fuel inlet pipe assembly-fuel transfer pump to secondary filter	1	9	CQ72314T5	Sealing gasket	2
	(104030-M80-0000)	Fuel inlet pipe assembly-filter to injection pump			(Q/WC3403-1994 M14X20)	Copper washer 14X20	
	(1104030-M80-0000W)	Fuel inlet pipe assembly-filter to injection pump		10	CQ72316T5	Sealing gasket	4
2	1104040-775	Fuel inlet pipe assembly-secondary filter to high-pressure fuel pump	1		(Q/XC3455 16PB)	Combination washer	
	(1104040-M80-0000)	Fuel inlet pipe assembly-fuel transfer pump to filter		11	1104011-775	Oil return pipe support (I)	1
3	1104050-775	Oil return pipe assembly	1		(1104011-M80-0000)		
	(1104050-M80-0000)			12	1104012-775	Tabletting of oil return pipe	2
4	1104070-775	Lubricating oil pipe assembly	1		(1104013-M80-0000)		
	(1104070-M80-0000)			13	1104013-775	Oil return pipe support (II)	1
5	1104036-73D	Hollow bolt-fuel transfer pump inlet and outlet	2		(1104012-M80-0000)		
	(1104084-81D)	Link bolt M16X1.5		14	CQ1500620	Hexagon bolt	2
6	1104073-D6	Hollow bolt-oil return pipe	1		(Q150B0620)		
	(1104083-81D)	Link bolt M14X1.5		15	Q40106	Plain washer	1
7	1104076-53D	Hollow bolt-lubricating oil pipe assembly	1	16	CQ34006	Hexagon nut	2
8	CQ72312T5	Sealing gasket	4		(Q340B06)	Type I hexagon nut	
	(Q/XC3455 12PB)	Combination washer					

