

37. Air compressor (II)

S/N	Part number	Part name	Qty.	S/N	Part number	Part name	Qty.
1	3509050-81D	Oil inlet pipe assembly	1	11	Q1841012	Hexagon flange bolt	1
	(3509050-81DK)						
2	3509053-29D	Bolt, connecting	2				
3	Q/WC3403-1994-3	Copper washer 10×16	4				
	(Q/WC3403-1994						
	10×16)						
4	3509020-81D	Air pressure pump water return pipe assembly	1				
5	Q/XC3451.1-2002	Bolt, connecting	4				
	(3509059-81D)	(Link bolt M18×1.5)					
6	Q/WC3403-1994	Copper washer 18×24	8				
7	3509030-81D	Air pressure pump water inlet pipe assembly	1				
8	3509032-81D	Bracket-air pressure pump oil inlet pipe	1				
9	3509314-74A	Intake pipe, air compressor	1				
	(3509041AM01-07						
	4A)						
10	Q67635B	Worm drive hose clamp	2				
	(Q67638)						




Fig. 37 Air compressor (II)