



调速器 Governor



498BT-3-12 10.12-调速器 GOVERNOR

标号 No.	代号 Code	名称 Description		数量 Quantity	备注 Remark
1	TQF001.1	飞块部件	FLY SHAFT PARTS	1	2011-11_
10	TQ001.3-19	调整垫片	ADJUSTING WASHER	2	2011-11_
11	TQ001.3-18	垫片	WASHER	2	2011-11_
12	GB896-86	挡圈 9	RING 9	1	
13	TQ001.3.1.3-03	丁字支承块	SUPPORTING PARTS	1	2011-11_
14	Gb818-85	螺钉 M6x10	SCREW M6X10	1	
15	GB859-76-Zn.D	垫圈 6	WASHER 6	1	
16	TQ001.3.1.2.1-01	调速弹簧挂钩	SPEED ADJUSTING SPRING HOOK	1	2011-11_
17	TQ001.3-01	调速弹簧	SPRING	1	2011-11_
18	TQ001.3.1.2.1-02	弹簧拉力板	SPRING	1	2011-11_
19	TQ002.1.1.1-01	调速臂	GOVERNOR SHAFT	1	2011-11_
2	TQ001-02	垫圈	WASHER	1	2011-11_
20	GB109-86	铆钉 4x11	RIVET 4X11	1	
21	GB290-89	轴承 HK081210	BEARING	1	
22	TQ001.3.1-03	隔套	SPACER BUSH	1	2011-11_
23	TQ001.3.1-04	调速杠杆垫圈	GOVERNOR LEVEL	2	2011-11_
24	TQ002.1.1-01	起动弹簧	SPRING	1	2011-11_
25	GB879-76	销 A3x16	PIN A3X16	1	
26	TQ001.3.1.2-02	镶块	SHAFT	1	2011-11_
27	TQ002.1.1.2-01	顶杆	TOP ROD	1	2011-11_
28	TQ002.1.1.2-02	弹簧	SPRING	1	2011-11_
29	TQ002.1.1.2-03	校正器螺套	BINDER BOLT CASE	1	2011-11_
3	GB6172-86	螺母 M5	SCREW M5	1	
30	GB808-88	螺母 M14	SCREW M14		
31	TQ001-01	密封垫	SEAL GASKET	1	2011-11_


调速器 Governor



498BT-3-12 10.12-调速器(续)

标号 No.	代号 Code	名称 Description	数量 Quantity	备注 Remark
32	TQ001.3-03	后壳	BACK PLATE	1 2011-11_
33	TQ001.3-12	高速限位螺钉	FIXING PIN	1 2011-11_
34	TQ001.3-13	高速限位螺母	FIXING SCREW	1 2011-11_
35	TQ001.2a	丝堵	SEAL	1 2011-11_
36	TQ001-04	垫圈	WASHER	1 2011-11_
37	TQ001.3-06	闷头	BULK HEAD	1 2011-11_
38	TQ001.3-04	标牌		1 2011-11_
4	TQ001-03	调速套筒	GOVERNOR CASE	1 2011-11_
40	TQ001.3-09	手柄销	SHAFT	2 2011-11_
45	TQ001.3-10b	调速手柄	GOVERNOR SHAFT	1 2011-11_
46	TQ001.3-11	回位弹簧	RETURN SPRING	1 2011-11_
48	TQ001.3-07	调速轴	GOVERNOR CAM	1 2011-11_
5	TQ001.3.1-02	联接杆	CONNECTING ROD	1 2011-11_
50	TQ001.3-02	弹簧摇臂	SPRING SHAFT	1 2011-11_
53	TQ001.3-08	调速轴调整垫片	WASHER	2 2011-11_
55	TQ001.3.3-02	停车轴垫圈	WASHER	1 2011-11_
55	TQ001.3.3-02	停车轴垫圈	WASHER	1 2011-11_
56	TQ002.1.2-01	停车轴连接板	CONNECTION PLATE	1 2011-11_
57	TQ001.3-16	回位弹簧	RETURN SPRING	1 2011-11_
59	TQ001.3.3-03	停车轴	STOP SHAFT	1 2011-11_
6	TQ001.3.1-01	联接销	CONNECT PIN	2 2011-11_
62	TQ001.3-17	中间轴	MIDDLE SHAFT	1 2011-11_
63	TQ001.3-21	放油螺钉	FUEL OUTPUT PIN	1 2011-11_
63	TQ001.3-21	放油螺钉	FUEL OUTPUT PIN	1 2011-11_
64	TQ001.3-20	垫圈	WASHER	1 2011-11_

调速器 Governor



498BT-3-12 10.12-调速器(续)

标号 No.	代号 Code	名称 Description		数量 Quantity	备注 Remark
7	TQ001.3.1-02	联接杆	CONNECTING ROD	2	2011-11_
71	TQ002.2-01c	停车拉线支架	STOP TRESTLE	1	2011-11_
73	TQ001.5-02a	后盖板	REAR COVER PLATE	1	2011-11_
73	TQ001.5-02a	后盖板	REAR COVER PLATE	1	2011-11_
74	TQ001-05	垫片	WASHER	1	2011-11_
75	TQ001.3-15	定位螺钉	LOCATING SCREW	1	2011-11_
76	TQ001.3-14	垫圈	WASHER	1	2011-11_
77	TQ001.3-05	垫圈	WASHER	2	2011-11_
79	TQ001.3.2-02	正校正器螺套	RETIFY BOLT CASE	1	2011-11_
8	TQ001.3.1.3-01	联接套	CONNECTION HOUSING	1	2011-11_
80	TQ001.3.2-07	正校正器弹簧	RETIFY SPRING	1	2011-11_
81	TQ001.3.2-01	正校正器顶杆	RETIFY LEVER	1	2011-11_
81	TQ001.3.2-01	正校正器顶杆	RETIFY LEVER	1	2011-11_
83	TQ001.3.2-04	预紧力调节螺套	ADJUSTBLE BOLT CASE	1	2011-11_
86	TQ001.3.2-05	护帽	CAP	1	2011-11_
87	GB3081-82	铅封丝	LEAD SEAL WIRE	999	2011-11_
88	R001-01	铅封	RIVET	1	2011-11_
9	TQ001.3.1.3-02	调速杠杆	ADJUSTABLE LEVEL	1	2011-11_