


汉德 13吨/16吨 STR驱动桥 Hande 13T/16T STR Driving Axle[HDS300]




车桥

50


AXLE

16吨中轴壳 16T Medium axle housing



序号 Item	件号 Part No.	名称	Name
1	HD91149330025	贯通驱动桥壳总成	Through driving axle housing assembly
2	DZ9114524031	后板簧左前支架	Rear spring front left bracket
	DZ9114524032	后板簧右前支架	Rear spring front right bracket
3	199014520256	销	Pin
4	190003901905	圆柱销	Cylindrical pin
5	DZ9114520305	左支架	Bracket (left)
	DZ9114520306	右支架	Bracket (right)
6	DZ9114520116	六角头螺栓	Hex bolt
7	190003989290	碗形堵塞	Bowling plug
8	190003888457	自锁螺母	Self-locking nut
9	190003810631	双头螺栓	Stud
10	190003901506	圆柱销	Cylindrical pin
11	DZ9112330623	磁性螺塞总成	Magnetic plug assembly
12	190003962021	锥螺纹内六角螺塞	Plug
13	81.35306.0034	直通接头	Straight joint
14	199014340042	气室支架总成	Chamber bracket
15	Q151B2040TF2	六角头螺栓	Hex bolt
	Q151B2030TF2	六角头螺栓	Hex bolt
16	1680M0320015	O型垫圈	O style seal ring
17	199014330126	操纵杆总成	Operation handle assembly
18	178000350055	ES平头销	Flat head pin
19	HD91129710001	电磁压力开关	Pressure switch
20	Q33208	2型全金属六角锁紧螺母	Hex nut
21	Q40108	平垫圈	Plain washer
22	161000060084	间隔衬套	Spacer bush
23	Q1200850F3	双头螺栓	Stud

13吨中桥桥壳 13T Medium axle housing




序号 Item	件号 Part No.	名称	Name
1	HD91129330097	贯通驱动桥壳总成	Rear axle housing assembly
2	DZ9114520629	后板簧左前支架	Spring bracket
	DZ9114520630	后板簧右前支架	Spring bracket
3	199014520256	销	Pin
4	190003901905	圆柱销	Pin
5	HD91129520007	左支架	Bracket (left)
	HD91129520008	右支架	Bracket (right)
6	DZ9114520116	六角头螺栓	Hex bolt
7	190003989290	碗形堵塞	Bowling plug
8	190003810631	双头螺栓	Stud
9	190003888457	自锁螺母	Self-locking nut
10	190003901506	圆柱销	Pin
11	199014330147	弓形固定卡 (上)	Bow hold-open catch assembly(upon)
	199014330146	弓形固定卡 (下)	Bow hold-open catch assembly(down)
12	Q2540820	十字槽沉头螺钉	Slit bolt
13	DZ9112330623	磁性堵塞总成	Magnetic plug assembly
14	190003962021	锥螺纹内六角螺塞	Plug
15	81.35306.0034	直通接头	Straight joint
16	199014340042	气室支架总成	Chamber bracket
17	Q151B2040TF2	六角头螺栓	Hex bolt
	Q151B2030TF2	六角头螺栓	Hex bolt
18	1680M0320015	O型垫圈	O style packing ring
19	199014330126	操纵杆总成	Operation handle assembly
20	178000350055	ES平头销	Flat head lock
21	HD91129710001	电磁压力开关	Pressure switch
22	Q33208	2型全金属六角锁紧螺母	Hex nut
23	Q40108	平垫圈	Plain washer
24	161000060084	间隔衬套	Space collar
25	Q1200850F3	双头螺栓	Stud

13吨/16吨中桥轮边 I

13T/16T Medium axle hub reduction I


序号 Item	件号 Part No.	名称	Name
1	DZ91129340111	隔圈	Spacer ring
2	199012340027	密封圈	Seal ring
3	30222	圆锥滚子轴承	Tapered roller bearing
4	DZ91129340119	后轮毂	Rear wheel hub assembly
5	32222	圆锥滚子轴承	Tapered roller bearing
6	188000420014	孔用挡圈	Circlip for hole
7	199012340121	内齿圈	Inner gear ring
8	H150A22120BZF3	车轮螺栓	Wheel bolt
9	190003884160	车轮螺母	Wheel nut
10	Q150B0816	六角头螺栓	Hex bolt
11	Q40308	弹簧垫圈	Spring washer
12	199012340021	挡油罩	Oil baffle cap
13	199012340020	密封垫片	Seal ring
14	DZ9112340221	半轴(左)	Axle shaft(left)
	DZ9112340222	半轴(右)	Axle shaft(right)
15	DZ9112340227	轮毂油封(左)	Axle oil ring(L)
	DZ9112340228	轮毂油封(右)	Axle oil ring(R)



13吨/16吨中桥轮边 II

13T/16T Medium axle hub reduction II

序号 Item	件号 Part No.	名称	Name
1	199112340018	行星架	Planet carrier
2	HD91129340053	行星轮垫片	Planet gear washer
3	DZ91129340090	滚针轴承	Needle bearing
4	DZ91129340093	行星轮	Planet gear
5	199012340004	行星轮轴	Planet gear axle
6	190003330148	钢球	Steel ball
7	199012340029	密封圈	Seal ring
8	Q2541025	十字槽沉头螺钉	Cross recessed countersunk head screw
9	HD91129340026	轮边减速器壳	Hub reduceor case
10	188000410097	垫圈	Washer
11	190003933351	轴用弹性挡圈	Circlip for axle
12	199012340011	端盖顶销	End cap pin
13	DZ91129340025	端盖	End cap
14	190003098026	密封垫圈	Seal ring
15	DZ9112346116	圆柱头内六角螺塞	Square head tapered plug
16	Q150B1014	六角头螺栓	Hex bolt
17	199012340005	太阳轮	Sun gear
18	199012340076	太阳轮垫圈	Sun gear washer
19	190003901704	圆柱销	Pin
20	Q151C1295TF2	六角头螺栓	Hex bolt
21	DZ91129340106	齿圈支架	Gear ring bearer
22	188000420033	齿圈座环	Gear ring seat ring
23	DZ9112340215	锁紧螺母	Circle nut
24	168000340015	止推垫圈	Stop washer
25	DZ9112340216	锁紧螺母	Locknut




车桥

53

AXLE


13吨/16吨中桥制动 I 13T/16T Medium axle brake I



序号 Item	件号 Part No.	名称	Name
1	188000340037	密封塞	Seal plug
2	Q150B0816	六角头螺栓	Hex bolt
3	Q40308	弹簧垫圈	Spring washer
4	199112340012	制动器防尘罩	Brake dust cap
5	199000340062	制动底板	Brake floor
6	190003963114	米制锥螺纹滑脂嘴	Taper thread grease nipple
7	188000340017	衬套	Bush
8	188000340023	O型密封圈	O ring
9	188000440010	附加垫片	Washer
10	190003933300	轴用弹性挡圈	Circlip for axle
11	DZ9112340056	制动凸轮轴 (左)	Brake camshaft (left)
12	DZ9112340057	制动凸轮轴 (右)	Brake camshaft (right)
13	188000440012	回位弹簧	Return spring
14	199000340027	滚轮	Roller wheel
15	199000340068	制动摩擦片	Brake friction plate
16	199000340061	制动蹄	Brake shoe
17	HD91129340028	制动鼓	Brake drum
18	Q2541020	十字槽盘头螺钉	Cross recessed pan head screw
19	189000340068	铆钉	Rivet
20	188000440032	回位弹簧销	Return spring pin
21	199000340064	支销	Backing pin
22	Q5280624	弹性圆柱销	Elastic cylindrical pin
23	199112340049	回位弹簧	Return spring
24	DZ9112340372	内六方圆柱头螺栓	Hex bolt

13吨/16吨中桥制动缸

13T/16T Medium axle brake III




序号 Item	件号 Part No.	名称	Name
1	AZ9100368303	膜片式弹簧制动气室	Diaphragm spring brake chamber
2	190003903661	销轴	Pin axle
3	Q40114	平垫圈	Flat washer
4	Q5004025	开口销	Cotter pin
5	Q43125	轴用弹性挡圈	Circlip for axle
6	108000320028	调整垫圈	Adjusting washer
	108000320029	调整垫圈	Adjusting washer
	108000320030	调整垫圈	Adjusting washer
	108000320046	调整垫圈	Adjusting washer
7	188000340022	垫圈	Washer
8	199000340056	间隙调整臂总成(左)	Automatic clearance adjusting (left)
	199000340057	间隙调整臂总成(右)	Automatic clearance adjusting(right)
9	188000340017	衬套	Bush
10	190003963114	米制锥螺纹滑脂嘴	Taper thread grease nipple
11	199014340041	凸轮轴支架	Camshaft bearer
12	138090470031	调整垫片	Adjusting washer
	138090470032	调整垫片	Adjusting washer
	138090470033	调整垫片	Adjusting washer
	188000340031	调整垫片	Adjusting washer
13	188000340032	调整垫片	Adjusting washer
	188000340033	调整垫片	Adjusting washer
	188000340034	调整垫片	Adjusting washer
14	Q151B1440	六角头螺栓	Hex bolt
15	Q151B1490	六角头螺栓	Hex bolt

车桥

55

AXLE


13吨/16吨中桥主减 I 13T/16T Medium axle final drive I



序号 Item	件号 Part No.	名称	Name
1	Q150B1025	六角头螺栓	Hex bolt
2	Q40310	弹簧垫圈	Spring washer
3	199014320175	端盖	Cover
4	Q150B1050	六角头螺栓	Hex bolt
5	Q340B10	1型六角螺母	Hex nut
6	190003902070	开槽圆柱头端紧定螺钉	Slotted screw
7	Q340B08	1型六角螺母	Hex nut
8	Q43117	轴用弹性挡圈	Circlip for axle
9	127000320037	衬套	Bush
10	128800730062	O形密封圈	O seal ring
11	199014320076	差速锁摇臂总成	Rocker arm
12	178000350055	ES平头销	Flat head pin
13	HD91129710001	电磁压力开关	Pressure switch
14	Q33208	2型全金属六角锁紧螺母	Hex nut
15	Q40108	平垫圈	Plain washer
16	161000060072	隔套	Spacer bush
17	199014320156	托架总成	Bearer assembly
18	Q150B0816	六角头螺栓	Hex bolt
19	Q40308	弹簧垫圈	Spring washer
20	DZ9112330620	加油螺塞总成	plug
21	190003901506	圆柱销	Pin
22	190003989279	碗形堵塞	Bowling choke plug
23	DZ9112330623	磁性螺塞总成	Magnetic plug assembly
24	HD90129320017	过桥箱盖	Pass-axle box cap
25	Q1201028F3	双头螺栓	Stud
26	199014320259	过桥箱	Pass axle box
27	Q340B12	1型六角螺母	Hex nut
28	Q40312	弹簧垫圈	Spring washer
29	Q1201225F3	双头螺栓	Stud
30	190003813628	双头螺栓	Stud
31	DZ91149320003	主减速器壳(中桥)	Final drive case
32	DZ9112320002	差速器轴承盖	Differential bearing cover
33	DZ90001500007	六角法兰面端面带齿螺栓	Hex bolt
34	199014320141	轴承座	Bearing seat
35	Q5210820	圆柱销	Pin
36	Q150B1020	六角头螺栓	Hex bolt
37	199014320118	接油板总成	Oil baffle assembly
	AZ9114320178	接油板总成	Oil baffle assembly

13吨/16吨中桥主减Ⅱ

13T/16T Medium axle final drive II



车桥


57

AXLE

序号 Item	件号 Part No.	名称	Name
1	DZ91129320007	凸缘螺母	Flange nut
2	DZ9112320632	凸缘	Flange
3	179000320012	防尘罩	Dust cap
4	DZ9112320920	主减油封	Seal ring for axle
5	Q433130	轴用压扁钢丝挡圈	Wire circlip for axle
6	6312N	深沟球轴承	Deep groove ball bearing
7	118000320077	拨叉活动块	Shifting fork block
8	199014320053	拨叉	Shifting fork
9	199014320061	轴间差速器壳垫片	Differential lock washer between axle
10	DZ9114320136	差速锁锁环	Differential lock ring
11	128800320106	差速锁销	Differential lock
12	HD91129320051	差速器壳(前)	Differential case (front)


序号 Item	件号 Part No.	名称	Name
13	HD90129320122	半轴齿轮(前)垫片	Axle shaft gear washer (front)
	HD90129320123	半轴齿轮(前)垫片	Axle shaft gear washer (front)
	HD90129320124	半轴齿轮(前)垫片	Axle shaft gear washer (front)
	HD90129320125	半轴齿轮(前)垫片	Axle shaft gear washer (front)
	HD90129320126	半轴齿轮(前)垫片	Axle shaft gear washer (front)
14	DZ9114320137	半轴齿轮(前)	Axle shaft gear (front)
15	DZ90129320000	差速器十字轴	Differential cross shaft
16	HD90129320121	衬套	Bush
17	DZ90129320003	行星齿轮	Planet gear
18	HD90129320120	行星齿轮垫片	Planet gear washer
19	199014320059	半轴齿轮(后)	Axle shaft gear (rear)
20	HD90129320127	半轴齿轮(后)垫片	Axle shaft gear washer (rear)
	HD90129320128	半轴齿轮(后)垫片	Axle shaft gear washer (rear)
	HD90129320129	半轴齿轮(后)垫片	Axle shaft gear washer (rear)
	HD90129320130	半轴齿轮(后)垫片	Axle shaft gear washer (rear)
21	HD91129320052	差速器壳(后)	differential case (rear)
22	Q151B1480TF2	六角头螺栓	Hex bolt
23	6019-Z	深沟球轴承	Deep groove ball bearing
24	190003933580	轴用弹性挡圈	Circlip for axle
25	DZ91129320066	空心轴	Hollow shaft
26	DZ91129320065	主动圆柱齿轮	Active cylindrical gear
	DZ91129320064	主动圆柱齿轮	Active cylindrical gear
	DZ91129320073	主动圆柱齿轮	Active cylindrical gear
27	199012250031	开槽圆螺母	Round nut
28	Q1801430TF2	六角法兰面带齿螺栓	Hex bolt
29	DZ91129320053	轴承压板	Bearing plate
30	Q33210	2型全金属六角锁紧螺母	Hex nut
31	DZ9114320129	31311轴承单元总成	Tapered roller bearing
32	199014320131	调整垫片	Adjusting washer
	199014320132	调整垫片	Adjusting washer
	199014320133	调整垫片	Adjusting washer
	199014320134	调整垫片	Adjusting washer
33	DZ91129320056	双头螺栓	Stud
34	DZ9114320651	从动圆柱齿轮	Passive cylindrical gear
	DZ9114320646	从动圆柱齿轮	Passive cylindrical gear
	DZ91129320074	从动圆柱齿轮	Passive cylindrical gear
35	DZ90129320074	满滚子圆柱滚子轴承	Roller bear
36	199014320256	钢丝挡圈	Steel wire circlip
37	199014320174	挡油片	Oil baffle
38	DZ9114320636	主动锥齿轮	Active bevel gear
39	DZ9114320138	贯通轴	Through axle
40	HD90149326033	四点接触球轴承	Ball bearing
41	DZ9114320902	贯通轴油封	Axle oil ring
42	DZ9114320654	凸缘	Flange

13吨/16吨中桥主减Ⅲ 13T/16T Medium axle final drive III




序号 Item	件号 Part No.	名称 Name
1	199012320014	拨叉 Shifting fork
2	118000320077	拨叉活动块 Shifting fork sliding block
3	199012320023	弯板 Bend plate
4	Q2800825	开槽锥端紧定螺钉 Slotted bolt
5	Q340B08	1型六角螺母 Hex nut
6	138090320156	滑动啮合套 Sliding engage sleeve
7	138090320157	圆螺母 Circle nut
8	138090320158	锁止垫片 Locking washer
9	138090320155	固定啮合套 Fixed engage sleeve
10	138090320159	差速器轴承调整螺母 Differential adjusting nut
11	190003326148	圆锥滚子轴承 Tapered roller bearing
12	DZ9114320013	六角法兰面承面带齿螺栓 Hex bolt
13	HD91129320045	差速器壳(左) Differential case (left)
14	HD90129320132	调整垫片 Adjusting washer
	HD90129320133	调整垫片 Adjusting washer
	HD90129320134	调整垫片 Adjusting washer
	HD90129320135	调整垫片 Adjusting washer
	HD90129320136	调整垫片 Adjusting washer
15	199012320009	半轴齿轮 Axle shaft gear
16	DZ90129320000	差速器十字轴 Differential spider
17	HD90129320121	衬套 Bush
18	DZ90129320003	行星齿轮 Planet gear
19	HD90129320120	行星齿轮垫片 Planet gear washer
20	199014320153	补偿环 Differential case washer
21	199014320126	从动锥齿轮 Passive bevel gear
22	HD91129320043	差速器壳(右) Differential case (right)
23	Q151B1480TF2	六角头螺栓 Hex bolt
24	DZ9112320083	止动片 Stop plate
25	Q40308	弹簧垫圈 Spring washer
26	Q150B0816	六角头螺栓 Hex bolt

16吨后桥桥壳 16T Rear axle housing



序号 Item	件号 Part No.	名称	Name
1	HD91149330027	驱动桥壳总成	Rear axle housing assembly
2	DZ9114524033	后板簧右后支架	Rear leaf spring right rear bracket
	DZ9114524034	后板簧左后支架	Rear leaf spring left rear bracket
3	199014520256	销	Pin
4	190003901905	圆柱销	Cylindrical pin
5	DZ9114520305	左支架	Bracket (left)
	DZ9114520306	右支架	Bracket (right)
6	DZ9114520116	六角头螺栓	Hex bolt
7	190003989290	碗形堵塞	Bowling plug
8	190003888457	自锁螺母	Self-locking nut
9	190003810631	双头螺栓	Stud
10	190003901506	圆柱销	Pin
11	DZ9112330623	磁性螺塞总成	Magnetic plug assembly
12	DZ9112330620	加油螺塞总成	Plug screw assembly
13	81.35306.0034	直通接头	Straight coupling
14	199014340042	气室支架总成	Chamber bracket
15	Q15182040TF2	六角头螺栓	Hex bolt
	Q15182030TF2	六角头螺栓	Hex bolt
16	1680M0320015	O型垫圈	O washer
17	199014330125	操纵杆总成	Operation handle assembly
18	178000350055	ES平头销	Flat head pin
19	HD91129710001	电磁压力开关	Pressure switch
20	Q33208	2型全金属六角锁紧螺母	Hex nut
21	Q40108	平垫圈	Plain washer
22	161000060084	间隔衬套	Spacer bush
23	Q1200850F3	双头螺栓	Stud

13吨后桥桥壳 13T Rear axle housing




序号 Item	件号 Part No.	名称	Name
1	HD91129330098	驱动桥壳总成	Rear axle housing assembly
2	DZ91129520032	后板簧右后支架	Spring bracket
3	DZ91129520033	后板簧左后支架	Spring bracket
4	199014520256	销	Pin
5	190003901905	圆柱销	Pin
6	HD91129520007	左支架	Bracket (left)
7	HD91129520008	右支架	Bracket (right)
8	DZ9114520116	六角头螺栓	Hex bolt
9	190003989290	碗形堵塞	Bowling plug
10	190003810631	双头螺栓	Self-locking nut
11	190003888457	自锁螺母	Pin
12	190003901506	圆柱销	Bow hold-open catch assembly(upon)
13	199014330147	弓形固定卡 (上)	Bow hold-open catch
14	199014330146	弓形固定卡 (下)	assembly(down)
15	Q2540820	十字槽沉头螺钉	Slit bolt
16	DZ9112330623	磁性螺塞总成	Magnetic plug assembly
17	DZ9112330620	加油螺塞总成	Plug screw assembly
18	81.35306.0034	直通接头	Straight coupling
19	199014340042	气室支架总成	Chamber bracket
20	Q151B2040TF2	六角头螺栓	Hex bolt
21	Q151B2030TF2	六角头螺栓	Hex bolt
22	1680M0320015	O型垫圈	O style packing ring
23	199014330125	操纵杆总成	Operation handle assembly
24	178000350055	ES平头销	Flat head lock
25	HD91129710001	电磁压力开关	Pressure switch
26	Q33208	2型全金属六角锁紧螺母	Hex nut
27	Q40108	平垫圈	Plain washer
28	161000060084	间隔衬套	Space collar
29	Q1200850F3	双头螺栓	Stud

车桥

61


AXLE

13吨/16吨后桥轮边 I 13T/16T Rear axle hub I




序号 Item	件号 Part No.	名称	Name
1	DZ91129340111	隔圈	Spacer ring
2	199012340027	密封圈	Seal ring
3	30222	圆锥滚子轴承	Tapered roller bearing
4	DZ91129340119	后轮毂	Rear wheel hub assembly
5	32222	圆锥滚子轴承	Tapered roller bearing
6	188000420014	孔用挡圈	Circlip for hole
7	199012340121	内齿圈	Inner gear ring
8	H150A221208ZF3	车轮螺栓	Wheel bolt
9	190003884160	车轮螺母	Wheel nut
10	Q15080816	六角头螺栓	Hex bolt
11	Q40308	弹簧垫圈	Spring washer
12	199012340021	挡油罩	Oil baffle cap
13	199012340020	密封垫片	Seal ring
14	DZ9112340221	半轴 (左)	Axle shaft(left)
15	DZ9112340222	半轴 (右)	Axle shaft(right)
	DZ9112340227	轮毂油封 (左)	Hub oil ring(L)
	DZ9112340228	轮毂油封 (右)	Hub oil ring(R)

13吨/16吨后桥轮边Ⅱ 13T/16T Rear axle hub Ⅱ




序号 Item	件号 Part No.	名称	Name
1	199112340018	行星架	Planet carrier
2	HD91129340053	行星轮垫片	Planet gear washer
3	DZ91129340090	滚针轴承	Needle bearing
4	DZ91129340093	行星轮	Planet gear
5	199012340004	行星轮轴	Planet gear axle
6	190003330148	钢球	Steel ball
7	199012340029	密封圈	Seal ring
8	Q2541025	十字槽沉头螺钉	Slotted screw
9	HD91129340026	轮边减速器壳	Hub reducer case
10	188000410097	垫圈	Washer
11	190003933351	轴用弹性挡圈	Circlip for axle
12	199012340011	端盖顶销	End cap pin
13	DZ91129340025	端盖	End cap
14	190003098026	密封垫圈	Seal ring
15	DZ9112346116	圆柱头内六角螺塞	Square head tapered plug
16	Q150B1014	六角头螺栓	Hex bolt
17	199012340005	太阳轮	Sun gear
18	199012340076	太阳轮垫圈	Sun gear washer
19	190003901704	圆柱销	Pin
20	Q151C1295TF2	六角头螺栓	Hex bolt
21	DZ91129340106	齿圈支架	Gear ring bearer
22	188000420033	齿圈座环	Gear ring seat ring
23	DZ9112340215	锁紧螺母	Circle nut
24	168000340015	止推垫圈	Stop washer
25	DZ9112340216	锁紧螺母	locknut

13吨/16吨后桥制动 I 13T/16T Rear axle brake I




序号 Item	件号 Part No.	名称	Name
1	188000340037	密封塞	Seal plug
2	Q150B0816	六角头螺栓	Hex bolt
3	Q40308	弹簧垫圈	Spring washer
4	199112340012	制动器防尘罩	Brake dust cap
5	199000340062	制动底板	Brake backplate
6	190003963114	米制锥螺纹滑脂嘴	Taper thread grease nipple
7	188000340017	衬套	Bush
8	188000340023	O型密封圈	O seal ring
9	188000440010	附加垫片	Washer
10	190003933300	轴用弹性挡圈	Circlip for axle
11	DZ9112340056	制动凸轮轴(左)	Brake camshaft (left)
	DZ9112340057	制动凸轮轴(右)	Brake camshaft (right)
12	188000440012	回位弹簧	Return spring
13	199000340027	滚轮	Roller wheel
14	199000340068	制动摩擦片	Brake friction plate
15	199000340061	制动蹄	Brake shoe
16	HD91129340028	制动鼓	Brake drum
17	Q2541020	十字槽盘头螺钉	Cross recess pan head screw
18	189000340068	铆钉	Rivet
19	188000440032	回位弹簧销	Return spring pin
20	199000340064	支销	Backing pin
21	Q5280624	弹性圆柱销	Elastic pin
22	199112340049	回位弹簧	Return spring
23	DZ9112340372	内六方圆柱头螺栓	Hex bolt

13吨/16吨后桥制动 II 13T/16T Rear axle brake II



序号 Item	件号 Part No.	名称	Name
1	AZ9100368303	膜片式弹簧制动气室	Diaphragm spring brake chamber
2	190003903661	销轴	Pin shaft
3	Q40114	平垫圈	Flat washer
4	Q5004025	开口销	Cotter pin
5	Q43125	轴用弹性挡圈	Circlip for axle
6	108000320028	调整垫圈	Adjusting washer
	108000320029	调整垫圈	Adjusting washer
	108000320030	调整垫圈	Adjusting washer
	108000320046	调整垫圈	Adjusting washer
7	188000340022	垫圈	Washer
8	199000340056	间隙调整臂总成(左)	Automatic clearance adjusting (left)
	199000340057	间隙调整臂总成(右)	Automatic clearance adjusting(right)
9	188000340017	衬套	Bush
10	190003963114	米制锥螺纹滑脂嘴	Taper thread grease nipple
11	199014340041	凸轮轴支架	Camshaft bearer
12	138090470031	调整垫片	Adjusting washer
	138090470032	调整垫片	Adjusting washer
	138090470033	调整垫片	Adjusting washer
13	188000340031	调整垫片	Adjusting washer
	188000340032	调整垫片	Adjusting washer
	188000340033	调整垫片	Adjusting washer
	188000340034	调整垫片	Adjusting washer
14	Q151B1440	六角头螺栓	Hex bolt
15	Q151B1490	六角头螺栓	Hex bolt

13吨/16吨后桥主减 13T/16T Rear axle final drive



序号 Item	件号 Part No.	名称	Name
1	DZ91129320007	凸缘螺母	Flange nut
2	DZ9112320632	凸缘 (φ180端面齿)	Flange
3	179000320012	防尘罩	Dust cap
4	199012320121	环	Ring
5	DZ9112320920	主减油封	Axle seal ring
6	30312	圆锥滚子轴承	Tapered roller bearing
7	188000320002	调整垫片	Adjusting washer
	188000320003	调整垫片	Adjusting washer
	188000320004	调整垫片	Adjusting washer
	188000320005	调整垫片	Adjusting washer
	188000320006	调整垫片	Adjusting washer
	188000320007	调整垫片	Adjusting washer
	188000320008	调整垫片	Adjusting washer
	188000320009	调整垫片	Adjusting washer
	188000320010	调整垫片	Adjusting washer
	188000320011	调整垫片	Adjusting washer
	188000320012	调整垫片	Adjusting washer
	188000320013	调整垫片	Adjusting washer
	188000320014	调整垫片	Adjusting washer
	188000320015	调整垫片	Adjusting washer

序号 Item	件号 Part No.	名称	Name
8	Q150B1230TF2	六角头螺栓	Hex bolt
9	199012320131	轴承座	Bearing seat
	199012320103	轴承座	Bearing seat
10	199012320133	密封圈	Seal ring
11	32316	圆锥滚子轴承	Tapered roller bearing
	32315	圆锥滚子轴承	Tapered roller bearing
12	DZ9112320626	主动圆锥齿轮	Bevel drive gear
	DZ9112320622	主动圆锥齿轮	Bevel drive gear
	DZ9112320620	主动圆锥齿轮	Bevel drive gear
13	199012320173	调整垫片	Adjusting washer
	199012320174	调整垫片	Adjusting washer
	199012320175	调整垫片	Adjusting washer
	199012320176	调整垫片	Adjusting washer
14	DZ91149320001	主减速器壳	Final drive housing
15	199112320001	从动锥齿轮	Bevel gear
	199012320125	从动锥齿轮	Bevel gear
	199012320035	从动锥齿轮	Bevel gear
16	AZ9112320153	衬环	Bush ring
17	HD91129320046	差速器壳 (左)	Differential housing (left)
	HD91129320042	差速器壳 (左)	Differential housing (left)
18	DZ9114320013	六角法兰面带齿螺栓	Hex bolt
19	32216	圆锥滚子轴承	Tapered roller bearing
20	138090320155	固定啮合套	Fixed engage sleeve
21	138090320158	锁止垫片	Locking washer
22	138090320157	圆螺母	Circle nut
23	138090320159	差速器调整螺母	Differential adjusting nut
24	138090320156	滑动啮合套	Sliding engage sleeve
25	118000320077	拨叉活动块	Sliding block
26	199012320014	拨叉	Shifting fork
27	199012320023	弯板	Bend plate
28	Q2800825	开槽锥端紧定螺钉	Slotted screw
29	Q340B08	I 型六角螺母	Hex nut
30	Q151B1480TF2	六角头螺栓	Hex bolt
31	HD91129320043	差速器壳 (右)	Differential housing (right)
32	HD90129320132	调整垫片	Adjusting washer
	HD90129320133	调整垫片	Adjusting washer
	HD90129320134	调整垫片	Adjusting washer
	HD90129320135	调整垫片	Adjusting washer
	HD90129320136	调整垫片	Adjusting washer
33	HD90129320120	行星齿轮垫片	Planet gear washer
34	DZ90129320003	行星齿轮	Planet gear
35	HD90129320121	行星齿轮衬套	Planet gear bush
36	199012320009	半轴齿轮	Axle shaft gear
37	DZ90129320000	十字轴	cross shaft
38	Q150B0816	六角头螺栓	Hex bolt
39	Q40308	弹簧垫圈	Spring washer
40	DZ9112320083	止动片	Stop piece
41	DZ90001500007	六角法兰面带齿螺栓	Hex bolt
42	DZ9112320002	差速器轴承盖	Differential bearing cover
43	Q5210820	圆柱销	Cylindrical pin