


汉德 MAN9.5吨 转向轴

Hande MAN9.5T Steering Axle(HDZ9.5)



车桥

47

AXLE

序号 Item	件号 Part No.	名称	Name
1	81.50221.0535	上制动摩擦片	Upper brake friction plate
	81.50221.0849	上制动摩擦片	Upper brake friction plate
2	81.50221.0540	下制动摩擦片	Lower brake friction plate
	81.50221.0948	下制动摩擦片	Lower brake friction plate
3	81.50211.0030	销	Pin
4	81.50213.0013	滚轮	Roller wheel
5	81.93021.0220	衬套	Bush
6	81.50212.0032	制动蹄销	Brake shoe pin
7	81.96501.0831	密封圈	Seal ring
8	DZ95009440001	衬套	Bush
9	81.92201.0109	空心铆钉	Hollow rivet
10	DZ95009440002	制动蹄	Brake shoe
	HD90009440079	制动蹄	Brake shoe
11	06.15113.2615	垫圈	Washer
12	190003933072	轴用弹性挡圈	Circlip for axle
13	81.97610.0115	回位弹簧	Return spring
14	81.50211.0018	回位弹簧销	Return pin
15	DZ95009440003	制动蹄总成	Brake shoe assembly
	HD95009440007	制动蹄总成	Brake shoe assembly
16	81.50301.0223	制动凸轮轴(左)	Brake camshaft (left)
	81.50301.0224	制动凸轮轴(右)	Brake camshaft (right)
17	81.50101.0223	防尘罩(左)	Dust cap (left)
18	81.96502.6040	轴密封圈	Axle Seal ring
19	81.50101.0224	防尘罩(右)	Dust cap (right)
20	81.93404.6005	滚针轴承	Needle bearing
	DZ9112440093	衬套	Bush
21	Q15081012	六角头螺栓	Hex bolt
22	81.96002.0098	密封堵	Seal plug
23	81.96002.0075	密封堵	Seal plug
24	Q184A1018TF2	六角法兰面螺栓	Hex bolt
25	81.90801.0225	护板	Protection block
26	Q151816125TF2	六角头螺栓-细牙	Hex bolt
27	Q15181645TF2	六角头螺栓-细牙	Hex bolt
28	Q15181640TF2	六角头螺栓-细牙	Hex bolt
29	81.50202.0108	制动底板	Brake backing plate
30	81.50310.0313	分泵支架(左)	Air-chamber bearer(left)
	81.50310.0312	分泵支架(右)	Air-chamber bearer(right)
31	190003963114	米制锥螺纹滑脂嘴	Grease nozzle
32	199000520096	保护罩	Protect cover
33	06.11241.0117	六角头螺母	Hex nut
34	Q15181690TF2	六角头螺栓-细牙	Hex bolt
35	81.96502.6039	轴密封圈	Axle Seal ring
36	81.91710.0163	隔套	Bushing
37	06.21569.0077	带头销钉(U型夹销)	Pin axle
38	81.50610.6231	自动间隙调整臂	Automatic clearance adjusting arm
39	Q40114	垫圈	Washer
40	Q5004025	开口销	Cotter pin
41	Q15080812	六角头螺栓	Hex bolt
42	81.90711.0714	指示片	Indicating plate
43	81.90711.0705	调整垫片	Adjusting washer
	81.90711.0706	调整垫片	Adjusting washer
	81.90711.0707	调整垫片	Adjusting washer
44	81.90701.0769	垫片	Washer
45	Q43134	轴用弹性挡圈	Circle for axle
46	HD95009360001	膜片制动气室24(左)	Brake air-chamber (left)
	HD95009360002	膜片制动气室24(右)	Brake air-chamber (right)
47	190003884160	车轮螺母	Wheel nut
48	H150A2287AZF3	车轮螺栓	Wheel bolt
49	Q2541020	十字槽沉头螺钉	Bolt

序号 Item	件号 Part No.	名称	Name
50	81.50110.0232	制动鼓	Brake drum
51	81.44312.0009	轮毂帽	Wheel hub cap
52	Q218B1040TF2	内六角圆柱头螺钉	Fixed bolt
53	81.92901.0066	锁紧螺母	Locknut
54	81.44215.0016	止推垫圈	Stop washer
55	HD95009410007	圆锥滚子轴承32310S	Tapered roller bearing
56	HD90009410004	挡油罩	Oil-proofing cover
57	HD90009410196	轮毂	Front wheel hub
58	HD90009410165	挡油罩	Oil-proofing cover
59	06.32499.0190	圆锥滚子轴承	Tapered roller bearing
60	06.56279.0340	轮毂油封	Hub oil seal
61	81.52403.0021	ABS脉冲齿圈	ABS pulse gear-ring
62	Q43068	孔用弹性挡圈	Circle for axle
63	81.44208.0009	密封盘	Seal disc
64	DZ9100410406	O型密封圈	Q style Seal ring
65	HD90009410358	上衬套	Top bush
66	HD90009410360	轴密封圈	Axle Seal ring
67	DZ9100580215	传感器衬套	Sensor bushing
	81.96002.0368	堵塞	Packing hulk head
68	DZ9100580214	传感器	Sensor
69	DZ9100410403	转向节臂	Knuckle arm
70	Q151B2480TF2	六角头螺栓-细牙	Hex bolt
71	Q341B16	1型六角螺母-细牙	Hex nut
72	HD95009410002	限位螺钉	Limiting screw
73	HD90009410191	转向梯形臂(左)	Steering trapezium arm (left)
	HD90009410192	转向梯形臂(右)	Steering trapezium arm (right)
	81.46701.0289	转向梯形臂(左)	Steering trapezium arm (left)
	81.46701.0290	转向梯形臂(右)	Steering trapezium arm (right)
74	Q151B2495TF2	六角头螺栓-细牙	Hex bolt
75	DZ9100410400	转向节(左)	Steering knuckle(left)
	DZ9100410401	转向节(右)	Steering knuckle(right)
76	06.56279.0343	轴密封圈	Axle Seal ring
77	06.33719.0097	滚针轴承	Needle bearing
78	DZ9100430090	横拉杆总成	Steering horizontal
79	81.90713.0679	调整垫片	Adjusting washer
	81.90713.0680	调整垫片	Adjusting washer
	81.90713.0681	调整垫片	Adjusting washer
	81.90713.0682	调整垫片	Adjusting washer
	81.90713.0683	调整垫片	Adjusting washer
	81.90713.0684	调整垫片	Adjusting washer
	81.90713.0685	调整垫片	Adjusting washer
	81.90713.0686	调整垫片	Adjusting washer
	81.90713.0687	调整垫片	Adjusting washer
	DZ9100410412	调整垫片	Adjusting washer
	DZ9100410413	调整垫片	Adjusting washer
	DZ9100410414	调整垫片	Adjusting washer
	DZ9100410415	调整垫片	Adjusting washer
	DZ9100410416	调整垫片	Adjusting washer
	DZ9100410417	调整垫片	Adjusting washer
	DZ9100410418	调整垫片	Adjusting washer
	DZ9100410419	调整垫片	Adjusting washer
80	HD90009410357	转向节主销	Steering knuckle pin
81	HD90009410375	前轴	Front axle
82	DZ9003326025	推力圆锥滚子轴承	Push tapered roller bearing